

**SCCR REPLACEMENT  
DISCONNECT COVER**

**INSTALLATION INSTRUCTIONS FOR SCCR REPLACEMENT DISCONNECT COVER  
USED ON LG/LD302-360**

**Shipping and Packing List**

Package 1 of 1 contains:

- 1- SCCR 100A Disconnect Cover
- 1- SCCR 200A Disconnect Cover
- 1- Front Disconnect Mullion Kit

**Application**

The SCCR disconnect cover protects the disconnect from the elements to ensure proper functioning and reliability. The cover comes in two variations for units rated at 100A and units rated at 200A.

**⚠ WARNING**

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Installation and service must be performed by a licensed professional HVAC installer or equivalent, service agency, or the gas supplier.

**⚠ CAUTION**

As with any mechanical equipment, contact with sharp sheet metal edges can result in personal injury. Take care while handling this equipment and wear gloves and protective clothing.

**Installation**

Screw cover on over disconnect. See FIGURE 1 for 100A units. See FIGURE 2 for 200A units.





FIGURE 1



SCCR - 200A

FIGURE 2