

KEY	COMPONENT
A96	CONTROL, INVERTER
A183	CONTROL, VFD BOARD
B3	MOTOR-BLOWER
DL58	DELAY, ADJUSTABLE, ON MAKE
F3	FUSE-ELECTRIC HEAT
F4	FUSE-UNIT
HE1	ELEMENT-ELECTRIC HEAT 1
HE2	ELEMENT-ELECTRIC HEAT 2
HE3	ELEMENT-ELECTRIC HEAT 3
HE4	ELEMENT-ELECTRIC HEAT 4
J/P246	JACK, PLUG-POWER TO VFD
J/P247	JACK, PLUG-VFD TO MOTOR
J/P248	JACK, PLUG-VFD CONTROL
K9-1	RELAY-HEAT
K15-1	CONTACTOR-ELECTRIC HT 1
K16-1	CONTACTOR-ELECTRIC HT 1
K19-1	RELAY-STAGE TWO HEAT
K32-1	RELAY-SEQUENCER, ELECTRIC HEAT 1
K43-1	RELAY-ECONOMIZER BLOWER
K220-1	RELAY-OVERFLOW
K232	RELAY-INVERTER PROTECTION
K264-1	RELAY-A96 SIGNAL SWITCHING
S15	SWITCH-LIMIT, PRIMARY ELECT HT
S20	SWITCH-LIMIT, SECONDARY ELECT HT
S49	SWITCH-FREEZE/STAT COMPRESSOR 1
S50	SWITCH-FREEZE/STAT COMPRESSOR 2
S149	SWITCH-OVERFLOW
T2	TRANSFORMER-ELECTRIC HEAT
TB1	TERMINAL STRIP-CLASS II VOLT
TB3	TERMINAL STRIP-ELECTRIC HEAT
TB13	TERMINAL STRIP-POWER DISTRIBUTION

- ⚠ S149 SWITCH AND K220 RELAY MAY BE FIELD SUPPLIED OR USE AVAILABLE KIT
- ⚠ S50 LOCATION ON UNITS WITH TWO COMPRESSORS
- ⚠ USE COPPER CONDUCTORS ONLY
- ⚠ S50 LOCATION ON UNITS WITH ONE COMPRESSOR
- ⚠ A96-S1, S2 CONNECTIONS ON E800 MODELS ONLY
- ⚠ DL58 DELAY MAY BE FIELD SUPPLIED OR USE AVAILABLE KIT


IF ANY WIRE IN THIS APPLIANCE IS REPLACED, IT MUST BE REPLACED WITH WIRE OF LIKE SIZE, RATING, INSULATION THICKNESS AND TERMINATION

WARNING-ELECTRIC SHOCK HAZARD, CAN CAUSE INJURY OR DEATH. UNIT MUST BE GROUNDED IN ACCORDANCE WITH NATIONAL AND LOCAL CODES

DISCONNECT ALL POWER BEFORE SERVICING

180, 240	KW	HE1	HE2	HE3	HE4
50	12.5	12.5	12.5	12.5	12.5

- LINE VOLTAGE FIELD INSTALLED
- ◀ DENOTES OPTIONAL COMPONENTS

2022/11		WIRING DIAGRAM	11/22
		538286-01	
HEATING - ELECTRIC			
T3EH - ELITE 180, 240 UNITS - G,J			
SECTION B3		REV 1	
Supersedes		New Form No.	
		538286-01	